

## Grommet eyelets

Grommet eyelets are reinforced metal rings set into the edges of screens, tarps and outdoor covers. They provide strong fixing points for ropes or bungees, helping secure the cover and prevent tearing under tension.

As standard, we use 12mm internal diameter eyelets (23mm external diameter), typically set into an approx 40mm reinforced hem. Eyelets are available in brass or silver nickel-plated finishes.

### Available colours





### Compatible products



#### Standard fixing spacing

As standard, turn buttons and eyelets are fitted at 50 cm intervals. This spacing can be adjusted during the product customisation process.



#### Video guide

Scan the QR code to watch a short video about turn buttons & eyelets or visit [go.kuvr.co/4qyFMgl](https://go.kuvr.co/4qyFMgl)



## Turn buttons

Turn buttons are a neat, low-profile alternative to eyelets, allowing screens and tarps to be quickly secured or released using a simple twist-lock mechanism,

Each turn button consists of two parts: a base with a rotating button fixed to the structure, and a specially shaped oval eyelet fitted into the fabric hem.

Turn buttons are available in single and double-height versions, with the double option allowing two buttons to be stacked while still enabling smooth rotation.

Screws are not supplied  
We recommend using M3.5 × 12 mm (No. 6 × ½") screws for fixing turn button base plates.

### Available colours



Turn buttons are not compatible with standard eyelets

Turn buttons cannot be used with standard circular eyelets. They must be selected at the time of ordering, they cannot be retrofitted.

