



1. Drawstring

A drawstring runs through the hem of the cover, allowing it to be pulled tight around the base of your items. This helps reduce excess fabric and keeps the cover sitting neatly in place.

It's a simple fixing option, best suited to sheltered areas or furniture that's easy to access all the way around. Drawstrings also make the cover quick to fit and remove.

This option is fitted as standard



2. Grommet Eyelets

Grommet eyelets are reinforced metal eyelets fitted along the edges of the cover, allowing it to be tied down using cords, bungees, or other suitable fixings. This provides a flexible and adjustable way to secure the cover firmly in place where specific anchor points are required.

They're especially useful for irregular shapes or fixed structures and offer a strong, reliable hold in more exposed or demanding areas.



3. Elasticated Corners

Elasticated corners are sewn into the lower edges of the cover, helping it grip the corners of your items and naturally hold its shape. This creates a cleaner, more tailored appearance without excess fabric or loose edges around the base.

They're ideal for objects with defined corners and provide a secure fit with minimal effort during fitting and removal. A popular option for everyday protection where ease of use matters.



4. Snap Buckles

Snap buckles secure the cover using adjustable straps that fasten underneath or around the item's frame. This fixing offers strong resistance to wind lift and movement, making it ideal for exposed areas or heavier covers.

5. Snap Buckles + Elasticated Corners

This option combines snap buckle security with elasticated corners, creating a neater, more tailored fit that stays firmly in place.